



NOTES:

1. LOCATE 3/4" AIR RELEASE VALVES AT ALL HIGH POINTS IN LINE AND AS CALLED FOR ON PLANS.
2. CORPORATIONS STOPS, FITTINGS AND RIGID PIPING SHALL BE BRASS. SERVICE SADDLES SHALL BE DOUBLE STRAP BRONZE.
3. AIR RELEASE VALVE MUST BE PLACED IN BOX SO IT MAY BE REMOVED WITHOUT REMOVING THE BOX.
4. METER BOX SIZE SHALL BE BROOKS #66, J&R 6B METER BOX OR APPROVED EQUAL. PLACE BOX AND VENT BEHIND SIDEWALK OR OUTSIDE TRAVELED WAY AS DIRECTED BY THE ENGINEER.
5. INSTALLATION LOCATIONS WHERE THERE IS A PARK STRIP OR NO SIDEWALK THE UNIT SHALL BE PLACED 6" BEHIND BACK OF CURB.

REVISION DATE	MADERA VALLEY WATER COMPANY		Std. Dwg.
10-15-08	AIR RELEASE VALVE		W-15
JAN 2013			